







Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact your local distributor for assistance.

A CAUTION: Use with product sheavier than the rated weights indicated may result in instability causing possible injury.

Please closely follow the assembly instructions. Improper installation may result in damage or serious personal injury.

Safety gear and proper tools must be used. This product should only be installed by professional all attached hardware and components.

Make sure that the supporting surface will safety support the combined weight of the equipment and all attached hardware and components.

Use the mounting screws provided and DO NOT OVER TIGHTEN mounting screws.

This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.

This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

IMPORTANT: Ensure that you have received all parts according to the component checklet prior to installation. If any parts are missing or faulty, contact your place of MAINTENANCE: Cheek that the product is series and safe to use at regular intervals (at least every three months).

MAINTENANCE: Check that the product is secure and safe to use at regular intervals (at least every three months).

TV Cart













